

Step 4: Install lead wires from new distributor to coil. The drawing below shows the most common wiring arrangements for the 226 6 cyl motor (12 volt).

Depending on date of manufacture for the new distributor the wiring codes are: RED = POSITIVE, BLACK = NEGATIVE OR BLACK = POSITIVE, BLUE = NEGATIVE. An external resistor will be needed if used with a standard coil. A coil with an internal resistor can also be used.

