



Questions?

Call us Toll Free at:

1-888-648-4923

(Mon-Fri, 9AM-5PM, EST) or email Mike

Meditz at: mike@kaiserwillys.com

INSTRUCTIONS FOR INSTALLING FIREWALL BOARD

1. PICTURE BELOW SHOWS FRONT OF BOARD, TO FACE THE ENGINE. ON BACK SIDE ARE PERFORATED HOLES. YOU HAVE TO PUNCH OUT THE HOLE WHICH IS INDICATED FOR YOUR SPECIFIC YEAR. FIVE ADDITIONAL HOLES ARE IF YOU HAVE AN ORIGINAL HEATER IN YOUR VEHICLE.
2. YOU HAVE TO PLACE SEVERAL LAYERS OF CORRIGATED CARDBOARD AGAINST METAL FIREWALL, BEFORE INSTALLING BLACK WATERPROOF CARDBOARD. THIS WAS THE ORIGINAL TYPE OF INSULATION USED. YOU CAN USE THE PACKING MATERIAL YOUR FIREWALL WAS PACKED IN. YOU MIGHT HAVE TO GET ADDITIONAL CARDBOARD TO FILL THE VOID.
3. 25 SCREWS AND SPEED NUTS ARE USED TO SECURE LAYERS OF CARDBOARD AND WATERPROOF BLACK CARDBOARD TO METAL FIREWALL.

