



Questions?

Call us Toll Free at:

1-888-648-4923

(Mon-Fri, 9AM-5PM, EST) or

email Mike Meditz at:

mike@kaiserwillys.com

Weber 32/36 Adaptor for the L134 'Go Devil'

Thank you for purchasing this Vintage Jeeper exclusive! This adaptor is designed to allow the fitment of a Weber DGV 32/36 Progressive or the Weber 38 to a Willys L134 flat head intake manifold typically found on the Willys CJ2A /CJ3A. This is considered a performance adaptor due to the polished venturi insert that allows better air flow and increased atomization of the fuel.

Before installing:

- Remove both intake studs from your existing intake manifold
- Ensure that the mounting surface is free of any gasket material and check for any burrs to ensure the adaptor sits flat. Failure to do this can lead to leaks and/or damage to the adaptor

Installation:

Step 1: The venturi insert is preinstalled in the adaptor, simply flip it over and it will slide out.

Step 2: The kit comes with a gasket that sits between the intake manifold and the adaptor. Coat both sides of the gasket with a light coat of Permatex #2 non hardening as well as the threads on the two adaptor mounting bolts.

Step 3: Install the adaptor to the manifold. Taking the 2 supplied mounting bolts, start by hand threading them into the manifold. Using allen wrench, tighten the bolts alternating from side to side until they are nice and snug (DO NOT OVER TIGHTEN).

Step 4: Install the venturi insert

Step 5: Install your Weber carburetor (Not included in the kit)