



Fuel Tank Exploded View

- | | |
|--|---|
| 1 & 22. B10331, 12021.87 - Fuel Tank Anti Squeak Welt Insulator Kit | 6 & 7. B0305 - Sending Unit Round Head Screw Set |
| 2. A1472K - Fuel Tank Hold Down Strap Kit | 8. 640696 - Rear Fuel Tank Hold Down Strap Clamp |
| 2. 663076 - Quarter Panel Fuel Tank Hold Down Strap Bracket | 13. 640594 - Black Fuel Tank Gas Cap |
| 2. A2953 - Inner Front Fuel Tank Hold Down Strap Bracket | 13. 908593 - Chrome Fuel Tank Gas Cap |
| 3. 640685 - Steel Fuel (gas) Tank (5 hole style sending unit) | 20. MS01200 - Formed Steel Fuel Line Kit |
| 3. 911895 - Steel Fuel (gas) Tank (6 hole style sending unit) | |
| 4. 635641A - Fuel Tank Sending Unit Gasket (6 hole) | 24-27. A1372K - Fuel Tank Strap & Hold Down Clamp Hardware Kit |
| 4. 648927 - Fuel Tank Sending Unit Gasket (5 hole) | |
| 5. 640694 - Fuel Tank Sending Unit (5 hole style sending unit) | |
| 5. 914850 - Fuel Tank Sending Unit (6 hole style sending unit) | |
| 5. 52705 - Fuel Gauge Wire to Tank Sending Unit Hardware Kit | |